

Well Water and Flooding

Your well could have been contaminated if it was compromised with the flood waters and should be tested once any discoloured water has been worked through the pumping system. Alberta Health Services has detailed information about well water testing on their website and you can use the links below to access such information.

<http://www.albertahealthservices.ca/services.asp?pid=service&rid=1052212>

<http://www.albertahealthservices.ca/Advisories/ne-pha-2011-07-14-faq-well-testing.pdf>

If your well had flood water introduced to it and you have any type of water treatment equipment in the home, the equipment should be inspected, serviced and sanitized by a qualified water treatment technician. Any water treatment equipment can easily become contaminated by the flood water and will remain contaminated until properly sanitized. It may be best to isolate the equipment using the bypass valves either supplied with equipment or plumbed in.

If you require further information or wish to have your unit serviced and sanitized by a qualified Certified Water Technician from EcoWater Systems Calgary, use the contact us page on our website or click the link below. <http://ecowatercalgary.ca/eco-water-systems-calgary>