

ELC – Series Reverse Osmosis Systems



ELC – Series Reverse Osmosis Systems are manufactured for light commercial applications and feature a compact space-saving design. The versatile design allows for either wall-mounted or freestanding operation. The ELC – Series Systems come preassembled and ready for immediate online service with minimal set up and simple utility connections.

ELC – Series Reverse Osmosis Systems have been engineered for capacities of 750 or 1,500 gallons per day and feature a Low Lead Brass Rotary Vane Pump designed for enhanced performance.

ELC – 1500
Reverse Osmosis System

Features

- White Powder Coated Steel Bracket
- 2.5" x 20" 5 – Micron Sediment Pre-Filter
- 2.5" x 20" 10 – Micron Carbon Block Pre-Filter (on ELC – 750)
- 20" Slim Line Cartridge Housings
- Low Lead Brass Rotary Vane High Pressure Pump
- ODP High Efficiency Carbonator Motor
- HF5 – Series Ultra Low Energy Membrane Elements
- Permeate Flow Meter
- Concentrate Flow Meter with SS Integrated Needle Valve
- Concentrate Recycle Flow Meter with SS Integrated Needle Valve
- Feed Solenoid Valve
- 0 – 300 psi Pump Pressure Gauge
- 0 – 100 psi Post-Filter Pressure Gauge
- 0 – 100 psi Permeate Pressure Gauge
- Push/Pull Fittings with Locking Safety Clips
- Low Pressure Switch for Pump Protection
- Permeate High Pressure Switch
- DM – 2 Dual TDS Meter
- 20" Floor Stand



ELC – Series Reverse Osmosis Systems

Product Specifications		
Models	ELC – 750	ELC – 1500
Design		
Configuration	Single Pass	Single Pass
Feedwater Source†	TDS <1,000 ppm	TDS <1,000 ppm
Standard Recovery Rate %	Up to 75	Up to 75
Rejection and Flow Rates †††		
Nominal Salt Rejection %	98.5	98.5
Permeate Flow (gpm / lpm)	0.52 / 1.97	1.04 / 3.94
Minimum Feed Flow (gpm / lpm)	2.22 / 8.40	2.74 / 10.37
Maximum Feed Flow (gpm / lpm)	Up to 8 / 30.3	Up to 8 / 30.3
Connections		
Feed Connection (in)	1/2 QC	1/2 QC
Permeate Connection (in)	3/8 QC	3/8 QC
Concentrate Connection (in)	3/8 QC	3/8 QC
Membranes		
Membrane(s) Per Vessel	1	1
Membrane Quantity	1	2
Membrane Size	3018	3018
Vessels		
Vessel Array	1	1:1
Vessel Quantity	1	2
Pumps		
Pump Type	Rotary Vane 401 Low Lead Brass	Rotary Vane 601 Low Lead Brass
Motor HP	1/3	1/2
RPM @ 60Hz	1725	1725
System Electrical		
Standard Voltage + Amp Draw	110V, 1 PH, 50 / 60Hz, 6.6A**	110V, 1 PH, 50 / 60Hz, 8.2A**
Systems Dimensions		
Approximate Dimensions* L x W x H (in / cm)	17 x 13 x 34 / 43.18 x 33.02 x 86.36	17 x 13 x 34 / 43.18 x 33.02 x 86.36
Approximate Weight (lbs / kg)	50 / 22.68	60 / 27.22

Test Parameters: 550 TDS Filtered (5 – Micron), Dechlorinated, Municipal Feedwater, 65 psi / 4.50 bar Feed Pressure, 70 psi / 4.83 bar Operating Pressure, 77°F / 25°C, Recovery as stated, 7.0 pH. Data taken after 60 minutes of operation.

* Does not include operating space requirements.

** Varies with motor manufacturer.

Operating Limits††

Maximum Feed Temperature (°F / °C)	85 / 29	Maximum Turbidity (NTU)	1
Minimum Feed Temperature (°F / °C)	40 / 4	Maximum Free Chlorine (ppm)	0
Maximum Ambient Temperature (°F / °C)	120 / 49	Maximum TDS (ppm)	Up to 1,000
Minimum Ambient Temperature (°F / °C)	40 / 4	Maximum Hardness (gpg)	1
Maximum Feed Pressure (psi / bar)	70 / 4	Maximum pH (Continuous)	11
Minimum Feed Pressure (psi / bar)	40 / 3	Minimum pH (Continuous)	2
Maximum Operating Pressure (psi / bar)	90 / 6	Maximum pH (Cleaning 30 Minutes)	13
Maximum Feed Silt Density Index (SDI)	<3	Minimum pH (Cleaning 30 Minutes)	1

† Low temperatures and feedwater quality, such as high TDS levels will significantly affect the systems production capabilities and performance. Computer projections must be run for individual applications which do not meet or exceed minimum and maximum operating limits for such conditions.

†† System pressure is variable due to water conditions. Permeate flow will increase at a higher temperature and will decrease at a lower temperature.

††† Product flow and maximum recovery rates are based on feedwater conditions as stated above. Do not exceed recommended permeate flow.



MKTF-505-B

800-228-9326 | www.ecowater.com



03/17 ©2018